



SafePak DK-1 Depository Kiosk

The SafePak DK-1 Depository accepts deposit bags up to 12" x 16" x 4" thick. A valid ID card is used to begin the process...and the LCD screen will prompt each step.

DEPOSIT ONLY ONE BAG AT A TIME.

The deposit door will be locked until the barcode printed on the first bag is scanned, and then unlocked to allow the first bag to be deposited. The deposit door will then automatically lock and the second bag can be scanned and deposited. The receipt will be printed, showing all deposited bags, when the deposit process is finished.

How To Make A Deposit



1. Insert/remove ID card



2. Enter # of bags to be deposited



3. Scan barcode on the first bag



4. Lift door, deposit bag and close door fully



5. Press "A" to repeat process for another bag, or...



6. Press "C" to get receipt

Questions? Problems? Call _____